


RESTART AUTOTEST PRO








A






	25 - 40A	10000A gL 63A
	63A	10000A gL 80A








AUX {
5÷230 Vac/dc
I_{max} = 100mA
(cosφ=1)
I_{min} = 0,6mA
AC12




**RESTART/
AUTOTEST ON**




**RESTART/
AUTOTEST OFF**





AUTOTEST




TEST RESTART









RESTART AUTOTEST PRO 2/4P









RESTART/AUTOTEST OFF


SET  		 0-OFF  I-ON 		AUX 	
		I-ON  		ON (t>15')	
		0-OFF  		OFF	
		I-ON  		ON	
		0-OFF  		ON	
		I-ON  		ON	KO!  
		0-OFF  		ON	KO!  

RESTART/AUTOTEST ON

SET  		 0-OFF  I-ON 		AUX 	
		I-ON  		OFF	
		0-OFF  		OFF	Restart (t<10s)
		I-ON  		OFF	Autotest (t<7s)
		0-OFF  		ON	 
		0-OFF  		ON	  
		I-ON  		ON	
		0-OFF  		ON	

		I-ON 		ON	KO!
		0-OFF 		ON	KO!





@

sat@gewiss.com
www.gewiss.com