






Auxiliary device to be used in combination with connected ZigBee rocker controls. When connected to the local inputs of the connected rocker controls, it allows replication of the local load control or sending ZigBee commands. The device must be completed with an interchangeable illuminated front key (codes from GWC2x030 to GWC2x047) and, if required, a front LED unit (e.g. GWA1802, GWA1807).

Category	Electronic push-button	LED colour	LED unit option (e.g. GWA1802, GWA1807)
No. modules	1	Button key	To be completed (code from GWC2x030 to GWC2x047)
Type of contact	1NO/NC 1 A (AC1) 240 V ac - Potential-free	Type of use	Relay, dimmer, bus contacts interfaces

DIMENSIONAL



STANDARDS/APPROVALS

